


Assembly Instructions

MODEL NO:EPS129/EPS159/EPS189



EFIFURNITURE



1


4PCS

* 4 x Double Ended Bolts
M5* 32mm - 6mm

Bolts only required when using
screen with Halo And Boost
Workstations

For instructions on how to attach
screen to Boost Or Halo
Workstation, refer to workstation
assembly instructions

STEP1



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

